



SNYPER·LTE+ / SPECTAUM V1 / V2 (EU/US) SOUICH STRET GUIDE

SNYPER-LTE+ / Spectrum Case Contents

- 1 SNYPER-LTE+ or SNYPER-LTE+ Spectrum
- 2 PSU with 4 Adapter Heads
- 3 0.5M USB Cable
- 4 USB Car Charger
- 5 Omni-directional Antennas General Purpose (Blue) and 2600MHz (Silver/Grey)*
- 6 LiveSCAN Directional Antenna (Spectrum model only)
- 7 1.5M Extension Cable for LiveSCAN Antenna (Spectrum model only)

*2600MHZ (Silver/Grev) antenna supplied for EU model only





· FIRST STEP BEFORE USE

► BATTERY CHARGE

Charge the unit for 4-6 hours or until the red charge light is extinguished.

SET TIME

- 1) Power up the SNYPER 😃- 🕒
- 2) Select 'Setup' from the 'Main Menu'
- 3) Select 'Set Time'
- 4) Use the keypad arrows to set date/time
- Use **C BACK** key to exit
- SOFTWARE UPDATE
 Go to https://www.siretta.com/snyper-plus
 to check for latest software.
- Your SNYPER is now ready to use



· 512727

- ► NEW SURVEY OPTIONS
 - 1) Select Full, LTE, UMTS or GSM*
 - 2) Press on to start survey
 - 3) Leave device to complete survey

*The SNYPER-LTE+ (USA) does not survey the GSM band.

- POST SURVEY OPTION 1
 - 1) Select 'Show Results'
 - 2) Press ov to start LiveSCAN (Spectrum only)
 - Use **C** BACK key to exit
- POST SURVEY OPTION 2
 - 1) Select 'Show Summary'
 - Use **C** BACK key to exit
- ► POST SURVEY OPTION 3
 - 1) Select 'Save Results'
 This is only necessary if Auto Save is off
 - Use **C** BACK key to exit

· 57VED RESULTS

- STORED SURVEY
 - 1) Select results file you wish to view
 - 2) Select 'Show Results', 'Show Summary' or 'Export Results'

Use **C BACK** key to exit

·SETUP

Language: ENG/DEU/FRA/ITA/SPA
Display: Screen brightness and text colours
Auto off: Auto switch off and dimming
Documents: File types and Auto Save
Sound: On/Off

System: Mode and region of operation Set Time: Set date and time

Reset Menu: Return to default settings

Use **C** BACK key to exit

· 720UT

\cdot PC CONNECT

- ► PC CONNECT
 - 1) Connect USB cable between device and PC
 - 2) Select ON to enable USB connection, begin results download
 - 3) Copy files required to PC
 - 4) Select OFF to disable connection

Use **C** BACK key to exit

You can then view results files on your PC

For safety documents, please visit: https://www.siretta.com/safety/

www.siretta.com

+44 (0)118 976 9000