




# RUT241






## **HARDWARE**


## **FRONT VIEW**



## **BACK VIEW**



## **POWER SOCKET PINOUT**





# **FEATURES**

MOBILE				
Mobile module	4G (LTE) – Cat 4 up to 150 Mbps, 3G – Up to 42 Mbps, 2G – Up to 236.8 kbps			
Status	Signal strength (RSSI), SINR, RSRP, RSRQ, EC/IO, RSCP, Bytes sent/received, connected band, IMSI, ICCID			
SMS	SMS status, SMS configuration, send/read SMS via HTTP POST/GET, EMAIL to SMS, SMS to EMAIL, SMS to HTTP, SMS to SMS, scheduled SMS, SMS autoreply, SMPP			
Black/White list	Operator black/white list			
Band management	Band lock, Used band status display			
APN	Auto APN			
Bridge	Direct connection (bridge) between mobile ISP and device on LAN			
Passthrough	Router assigns its mobile WAN IP address to another device on LAN			
Multiple PDN (optional)	Possibility to use different PDNs for multiple network access and services (not available in standard FW)			
WIRELESS				
Wireless mode	IEEE 802.11b/g/n, Access Point (AP), Station (STA)			
WiFi security	WPA2-Enterprise - PEAP, WPA2-PSK, WEP, WPA-EAP, WPA-PSK; AES-CCMP, TKIP, Auto Cipher modes, client separation			
SSID	SSID stealth mode and access control based on MAC address			
WiFi users	Up to 50 simultaneous connections			
Wireless Hotspot	Captive portal (Hotspot), internal/external Radius server, built in customizable landing page			
ETHERNET				
WAN	1 x WAN port (can be configured to LAN) 10/100 Mbps, compliance with IEEE 802.3, IEEE 802.3u standards, supports auto MDI/MDIX			
LAN	1 x LAN port, 10/100 Mbps, compliance with IEEE 802.3, IEEE 802.3u standards, supports auto MDI/MDIX			
NETWORK				
Routing	Static routing, Dynamic routing (BGP, OSPF v2, RIP v1/v2, RIPng, OSPF6)			
Network protocols	TCP, UDP, IPv4, IPv6, ICMP, NTP, DNS, HTTP, HTTPS, FTP, SMTP, SSL v3, TLS, ARP, VRRP, PPP, PPPoE, UPnP, SSH, DHCP, Telnet client, SNMP, MQTT, Wake On Lan (WOL)			
VoIP passthrough support	H.323 and SIP-alg protocol NAT helpers, allowing proper routing of VoIP packets			
Connection monitoring	Ping Reboot, Wget Reboot, Periodic Reboot, LCP and ICMP for link inspection			
Firewall	Port forward, traffic rules, custom rules			
DHCP	Static and dynamic IP allocation, DHCP Relay, Relayd			
QoS / Smart Queue Management (SQM)	Traffic priority queuing by source/destination, service, protocol or port, traffic priority queuing by source/destination, service, protocol or port, WMM, 802.11e			
DDNS	Supported >25 service providers, others can be configured manually			
Network backup	VRRP, Mobile, Wired and WiFi WAN options, each of which can be used as backup, using automatic Failover			
Load balancing	Balance your internet traffic over multiple WAN connections			
SSHFS (optional)	Possibility to mount remote file system via SSH protocol (not available in standard FW)			
SECURITY				
Authentication	Pre-shared key, digital certificates, X.509 certificates			
Firewall	Pre-configured firewall rules can be enabled via WebUI, unlimited firewall configuration via CLI; DMZ; NAT; NAT-T			
Attack prevention	DDOS prevention (SYN flood protection, SSH attack prevention, HTTP/HTTPS attack prevention), port scan prevention (SYN-FIN, SYN-RST, X-mas, NULL flags, FIN scan attacks)			
VLAN	Port and tag based VLAN separation			
Mobile quota control	Set up custom data limits for the SIM card			
WEB filter	Blacklist for blocking out unwanted websites, whitelist for specifying allowed sites only			
Access control	Flexible access control of TCP, UDP, ICMP packets, MAC address filter			



VPN			
OpenVPN	Multiple clients and server can be running simultaneously, 12 encryption methods		
OpenVPN Encryption	DES-CBC, RC2-CBC, DES-EDE-CBC, DES-EDE3-CBC, DESX-CBC, BF-CBC, RC2-40-CBC, CAST5-CBC, RC2-64-CBC, AES-128-CBC, AES-192-CBC, AES-256-CBC		
IPsec	IKEv1, IKEv2, supports up to 4 x VPN IPsec tunnels (instances), with 5 encryption methods (DES, 3DES, AES128, AES192, AES2		
GRE	GRE tunnel		
PPTP, L2TP	Client/Server services can run simultaneously		
Stunnel	Proxy designed to add TLS encryption functionality to existing clients and servers without any changes in the programs' code		
SSTP	SSTP client instance support		
ZeroTier	ZeroTier VPN		
WireGuard	WireGuard VPN client and server support		
MODBUS TCP SLAVE			
ID filtering	Respond to one ID in range [1;255] or any		
Allow Remote Access	Allow access through WAN		
Custom registers	MODBUS TCP custom register block requests, which read/write to a file inside the router, and can be used to extend MODBUS TCP Slave functionality		
MODBUS TCP MASTER			
Supported functions	01, 02, 03, 04, 05, 06, 15, 16		
Supported data formats	8 bit: INT, UINT; 16 bit: INT, UINT (MSB or LSB first); 32 bit: float, INT, UINT (ABCD (big-endian), DCBA (little-endian), CDAB, BADC)		
MODBUS DATA TO SERVER			
Protocol	HTTP(S), MQTT, Azure MQTT		
MQTT GATEWAY			
MQTT gateway	Allows sending commands and receiving data from Modbus Master through MQTT broker		
MONITORING & MANAGEN	MENT		
WEB UI	HTTP/HTTPS, status, configuration, FW update, CLI ,troubleshoot, event log, system log, kernel log		
FOTA	Firmware update from sever, automatic notification		
SSH	SSH (v1, v2)		
SMS	SMS status, SMS configuration, send/read SMS via HTTP POST/GET		
Call	Reboot, Status, WiFi on/off, Mobile data on/off, Output on/off		
TR-069	OpenACS, EasyCwmp, ACSLite, tGem, LibreACS, GenieACS, FreeACS, LibCWMP, Friendly tech, AVSystem		
MQTT	MQTT Broker, MQTT publisher		
SNMP	SNMP (v1, v2, v3), SNMP trap		
JSON-RPC	Management API over HTTP/HTTPS		
MODBUS	MODBUS TCP status/control		
RMS	Teltonika Remote Management System (RMS)		
IoT PLATFORMS			
Clouds of things	Allows monitoring of: Device data, Mobile data, Network info, Availability		
ThingWorx	Allows monitoring of: WAN Type, WAN IP Mobile Operator Name, Mobile Signal Strength, Mobile Network Type		
Cumulocity	Allows monitoring of: Device Model, Revision and Serial Number, Mobile Cell ID, ICCID, IMEI, Connection Type, Operator, Signal Strength, WAN Type and IP		
Azure IoT Hub	Can send device IP, Number of bytes send/received/ 3G connection state, Network link state, IMEI, ICCID, Model, Manufacturer Serial, Revision, IMSI, Sim State, PIN state, GSM signal, WCDMA RSCP WCDMA EC/IO, LTE RSRP, LTE SINR, LTE RSRQ, CELL ID, Operator, Operator number, Connection type, Temperature, PIN count to Azure IoT Hub server		



C/	/CT		CHA	١D٨	CTE	DIG	CTIC	c
<b>.</b>		I LIVI	CI 17	$\neg$		. I X I s	שוו כ	J

CPU	Mediatek, MT7628, 580 MHz
RAM	128 MB, DDR2
FLASH storage	16 MB, SPI Flash

## FIRMWARE / CONFIGURATION

WEB UI	Update FW from file, check FW on server, configuration profiles, configuration backup, restore point		
FOTA	Update FW/configuration from server		
RMS	Update FW/configuration for multiple devices		
Keep settings	Update FW without losing current configuration		

## FIRMWARE CUSTOMIZATION

Operating system	RutOS (OpenWrt based Linux OS)
Supported languages	Busybox shell, Lua, C, C++
Development tools	SDK package with built environment provided

#### INPUT/OUTPUT

Input	1 x Digital input, 0 - 5 V detected as logic low, 8 - 30 V detected as logic high
Output	1 x Digital open collector output, max output 30 V, 300 mA
Events	SMS FMAIL RMS

## **POWER**

Connector	4 pin industrial DC power socket
Input voltage range	9 – 30 VDC, reverse polarity protection, surge protection >33 VDC 10us max
PoE (passive)	Passive PoE over spare pairs (available from HW revision 0007 and batch number 0010). Possibility to power up through LAN port, not compatible with IEEE802.3af, 802.3at and 802.3bt
Power consumption	< 6.5 W Max

## PHYSICAL INTERFACES (PORTS, LEDS, ANTENNAS, BUTTONS, SIM)

Ethernet	2 x RJ45 ports, 10/100 Mbps
I/Os	1 x Digital Input, 1 x Digital Output on 4 pin power connector
Status LEDs	3 x Connection type status LEDs, 5 x Connection strength LEDs, 2 x LAN status LEDs, 1 x Power LED
SIM	1 x SIM slot (Mini SIM – 2FF), 1.8 V/3 V, external SIM holder
Power	1 x 4 pin DC connector
Antennas	2 x SMA for LTE, 1 x RP-SMA for WiFi antenna connectors
Reset	Reboot/Factory reset button

## PHYSICAL SPECIFICATION

Casing material	Aluminium housing with DIN rail mounting option, plastic panels
Dimensions (W x H x D)	83 x 25 x 74 mm
Weight	125 g
Mounting options	Bottom and sideways DIN rail mounting slots

## **OPERATING ENVIRONMENT**

Operating temperature	-40 C to 75 C
Operating humidity	10 % to 90 % non-condensing
Ingress Protection Rating	IP30

## REGULATORY & TYPE APPROVALS

Regulatory CE/RED, UKCA, CB



## **EMI IMMUNITY**

Standards


Standards	EN 301 489-1 V2.2.3 EN 301 489-17 V3.2.4 Final draft EN 301 489-52 V1.2.0 EN 55032:2015+A1:2020 EN 55035:2017+A11:2020 EN 61000-3-3:2013+A1:2019 EN IEC 61000-3-2:2019
ESD	EN 61000-4-2:2009
Radiated Immunity	EN 61000-4-3:2020
EFT	EN 61000-4-4:2012
Surge Immunity (AC Mains Power Port)	EN 61000-4-5:2014+A1:2017
Conducted Immunity	EN 61000-4-6:2014
DIP	EN IEC 61000-4-11:2020
RF	
Standards	EN 300 328 V2.2.2, EN 301 511 V12.5.1, EN 301 908-1 V13.1.1, EN 301 908-2 V13.1.1, EN 301 908-13 V13.1.1
SAFETY	

EN IEC 62311:2020, EN 50665:2017, EN IEC 62368-1:2020+A11:2020, IEC 62368-1:2018



## HARDWARE INSTALLATION

- 1. Push the SIM button with the SIM needle.
- 2. Pull out the SIM holder.
- 3. Insert your SIM card into the SIM holder.
- 4. Slide the SIM holder back into the router.
- 5. Attach Mobile and WiFi antennas.
- 6. Connect the power adapter to the socket on the front of the device. Then plug the other end of the power adapter into a power outlet.
- 7. Connect to the device wirelessly using SSID and password provided on the device information label or use an Ethernet cable connected to LAN port.



## **LOGIN TO DEVICE**

- 1. To enter the router's Web interface (WebUI), type http://192.168.1.1 into the URL field of your Internet browser.
- 2. Use login information shown in image A when prompted for authentication.
- 3. After you log in, you will be prompted to change your password for security reasons. The new password must contain at least 8 characters, including at least one uppercase letter, one lowercase letter, and one digit. This step is mandatory, and you will not be able to interact with the router's WebUI before you change the password.
- 4. When you change the router's password, the Configuration Wizard will start. The Configuration Wizard is a tool used to set up some of the router's main operating parameters.
- 5. Go to the Overview page and pay attention to the Signal Strength indication (image B). To maximize the cellular performance try adjusting the antennas or changing the location of your device to achieve the best signal conditions.





#### **TECHNICAL INFORMATION**

Radio specifications		
RF technologies	2G, 3G, 4G, WiFi	
Max RF power	33 dBm@GSM, 24 dBm@WCDMA, 23 dBm@LTE, 20 dBm@ WiFi	
Bundled accessories specifications*		
Power adapter	Input: 0.4 A@100-240 VAC, Output: 9 VDC, 1A, 4-pin plug	
Mobile antenna	698~960 / 1710~2690 MHz, 50 Ω, VSWR<3, gain** 4 dBi, omnidirectional, SMA male connector	
WiFi antenna	2400~2500 MHz, 50 Ω, VSWR<2.5, gain** 5 dBi, omnidirectional, RP-SMA male connector	

<sup>\*</sup>Order code dependent

<sup>\*\*</sup>Higher gain antenna can be connected to compensate for cable attenuation when a cable is used. The user is responsible for the compliance with the legal regulations.




# WHAT'S IN THE BOX?

## STANDARD PACKAGE CONTAINS\*

- Router RUT241
- 9 W PSU
- 2 x LTE antennas (swivel, SMA male)
- 1 x WiFi antenna (swivel, RP-SMA male)
- Ethernet cable (1.5 m)
- SIM Adapter kit
- QSG (Quick Start Guide)
- RMS Flyer
- Packaging box





 $<sup>\</sup>ensuremath{\mbox{*}}$  For all standard order codes standard package contents are the same, execpt for PSU.



# **STANDARD ORDER CODES**

PRODUCT CODE	HS CODE	HTS CODE	PACKAGE CONTAINS
RUT241 010000	851762	8517.62.00	Standard package with Euro PSU
RUT241 011000	851762	8517.62.00	Standard package with US PSU

For more information on all available packaging options – please contact us directly.

# **AVAILABLE VERSIONS**

PRODUCT CODE	REGION (OPERATOR)	FREQUENCY
RUT241 *0****	Europe, the Middle East, Africa, Korea, Thailand	<ul><li>4G (LTE-FDD): B1, B3, B7, B8, B20, B28A</li><li>3G: B1, B8</li><li>2G: B3, B8</li></ul>
RUT241 *1****	Europe, the Middle East, Africa	<ul> <li>4G (LTE-FDD): B1, B3, B5, B7, B8, B20</li> <li>4G (LTE-TDD): B40</li> <li>3G: B1, B5, B8</li> <li>2G: B3, B8</li> </ul>

The price and lead-times for region (operator) specific versions may vary. For more information please contact us. 1 - Router is not certified on T-Mobile, Bell network (In progress).



# **MOUNTING OPTIONS**

## **DIN RAIL KIT**

Parameter	Value
Mounting standard	35mm DIN Rail
Material	Low carbon steel
Weight	57g
Screws included	Philips Pan Head screw #6-32×3/16, 2pcs
Dimensions	82 mm x 46 mm x 20 mm
RoHS Compliant	V

## **DIN RAIL KIT**

- DIN Rail adapter
- Philips Pan Head screw #6-32×3/16, 2pcs for RUT2xx/RUT9xx



ORDER CODE	HS CODE	HTS CODE
PR5MEC00	73269098	7326.90.98

For more information on all available packaging options – please contact us directly.

## **COMPACT DIN RAIL KIT**

Parameter	Value
Mounting standard	35mm DIN Rail
Material	ABS + PC plastic
Weight	6.5 g
Screws included	Philips Pan Head screw #6-32×3/16, 2pcs
Dimensions	70 mm x 25 mm x 14,5 mm
RoHS Compliant	V

## **DIN RAIL KIT**

- Compact plastic DIN Rail adapter (70x25x14,5mm)
- Philips Pan Head screw #6-32×3/16, 2pcs

ORDER CODE	HS CODE	HTS CODE
PR5MEC11	73269098	7326.90.98

For more information on all available packaging options – please contact us directly.

## **SURFACE MOUNTING KIT**

Parameter	Value
Mounting standard	Flat surface mount
Material	ABS + PC plastic
Weight	2x5 g
Screws included	Philips Pan Head screw #6-32×3/16, 2pcs
Dimensions	25 mm x 48 mm x 7.5 mm
RoHS Compliant	V

## **DIN RAIL KIT**

- Surface mounting kit
- Philips Pan Head screw #6-32×3/16, 2pcs

ORDER CODE	HS CODE	HTS CODE
PR5MEC12	73269098	7326.90.98

For more information on all available packaging options – please contact us directly.





## **RUT241 SPATIAL MEASUREMENTS & WEIGHT**


## **MAIN MEASUREMENTS**

W x H x D dimensions for RUT241:

Device housing\*: 83 x 25 x 74
Box: 173 x 71 x 148


## **TOP VIEW**

The figure below depicts the measurements of RUT241 and its components as seen from the top:



## **RIGHT VIEW**

The figure below depicts the measurements of RUT241 and its components as seen from the right side:  $\frac{1}{2} \left( \frac{1}{2} \right) = \frac{1}{2} \left( \frac{1}{2} \right) \left( \frac{1}$ 




<sup>\*</sup>Housing measurements are presented without antenna connectors and screws; for measurements of other device elements look to the sections below.




## **FRONT VIEW**

The figure below depicts the measurements of RUT241 and its components as seen from the front panel side:



## **REAR VIEW**


 $The figure \ below \ depicts \ the \ measurements \ of \ RUT241 \ and \ its \ components \ as \ seen \ from \ the \ back \ panel \ side:$ 





## MOUNTING SPACE REQUIREMENTS

 $The figure \ below \ depicts \ an \ approximation \ of the \ device's \ dimensions \ when \ cables \ and \ antennas \ are \ attached:$ 





## **DIN RAIL**

The scheme below depicts protrusion measurements of an attached DIN Rail:

